


# SIDEWINDER II ILLUSTRATED PARTS LIST



SW501

Item	Part Number	Description	Notes
1	R00670	Lead Rail	8'
	R00558		9'
	R00671		10'
2	R00396	End Cap	2 per pkg
	R00584		
3	R00585	Rafter Assy	8'
	R00585		9' - 10'
4	R00586	Rafter Retainer, Rubber	
	R00581		
	R00582		
	R00583		
	R00573		9' - 12'
	R00687		UPS Shippable
6	R00353	Pivot Block	
7	R00144	Flipper Latch Assy	
8	R00587	Telescoping Extender	6' - 8'
9	R00394	Carport Foot	
10	R00038	Bottom Bracket Assy	
	R00578		
11	R00578	Housing Assy	8'
	R00579		9'
	R00580		10'
12	R00433	End Cap, Cover, RH	
13	R00432	End Cap, Cover, LH	
14	R00436	End Cap Assy, Housing, RH	
15	R00435	End Cap Assy, Housing, LH	
16		Canopy Only	Refer to Canopy Order Form
17	R00588	Hardware Pack	Not Shown

This Manual is Compliments of

# Northwest RV Supply

86325 College View Road  
Eugene, OR 97405

Local: 541-746-9092

Toll-Free: 866-678-7467

Fax: 541-736-5573

<http://www.nwrvsupply.com>  
[mail@nwrvsupply.com](mailto:mail@nwrvsupply.com)

Northwest RV Supply carries a large spectrum of surplus, used, and new RV parts and components. Please feel free to visit our website for additional information.